



Contains small parts. Not suitable for young children. Designed for hobby use. Not suitable for commercial, industrial or safety-critical use.

SC710 v1.0.x  
Printed circuit board



1


C1 to C12  
100 nF



12

Label includes "104"


JP1 to JP22 Header  
2 row x 40 pin straight



2


See note 1

Jumper shunt



76


K1 to K12 Female  
2 row x 40 pin straight



12


See note 2 and 3

P1 Male  
2 row x 40 pin angled




1

S1 Header socket  
2 row x 40 pin angled




1

Spacer  
Nylon, 10mm, M3



12

Screw (for spacer)  
M3, 6mm, pan head



24


Notes:

1/ Cut into short length strips, 3 and 5 pins long, for J1 to JP22 (long nose wire cutters work well)

2/ Ensure the module sockets (K1 to K6) are pressed firmly against the PCB along their entire length

3/ Use either 2 x 40 pin sockets (double row) or pairs of 1 x 40 pin sockets (single row)

Kits may be supplied with single row sockets due to recent quality issues with double row sockets



# Welcome to your SC710, Backplane Kit

Assembly instructions, user guide, and other documentation can be found at [www.scc.me.uk](http://www.scc.me.uk) (small computer central)

Release date: 2023-05-01

TITLE: SC710 - Kit Contents		REV: 1.0.2
Designed for RCBus	Company: <a href="http://www.scc.me.uk">www.scc.me.uk</a>	Sheet: 1/1
	Date: 2025-05-30	Drawn By: sccousins